

Mr. G's Enterprises

5613 Elliott Reeder Road • Fort Worth, Texas 76117-6013

(817) 831-3501 • Fax # (817) 831-0638 • email : mrgs@mrgusa.com Webiste: www.mrgusa.com

Mopar Exterior Screw Kits

<u>Kit #</u>	<u>Year</u>	<u>Make/Model</u>	<u>Description</u>	<u>Screw Quantity</u>	<u>Price</u>
MO 504	1962	Dodge Dart 330		(16 Screws)	7.20
MO 1590	1963	Dodge Dart		(34 Screws)	15.10
MO 1595	1964	Dodge Dart		(40 Screws)	15.50
MO 505	1965	Dodge Dart GT		(38 Screws)	15.90
MO 505 A	1965	Dodge Dart GT		(70 Screws)	28.70
MO 506	1965	Dodge Dart		(20 Screws)	7.70
MO 506 A	1965	Dodge Dart	Ext. Kit w/Wheel Well	(52 Screws)	20.50
MO 1985	1969	Dodge Dart		(20 Screws)	9.30
MO 1985 A	1969	Dodge Dart	Ext. Kit w/Wheel Well	(52 Screws)	22.10
MO 1980	1970-72	Dodge Dart		(24 Screws)	11.30
MO 1980 A	1970-72	Dodge Dart	Ext. Kit w/Wheel Well	(56 Screws)	23.30
MO 1975	1975	Dodge Dart		(17 Screws)	6.20
MO 602	1970-74	Dodge Challenger		(28 Screws)	14.00
MO 602 A	1970-74	Dodge Challenger	Ext. Kit w/Wheel Well	(60 Screws)	26.80
MO 804	1970-74	Dodge Challenger	Rear Valance Mounting Kit	(33 Screws)	22.05
MO 1930	1966-67	Dodge Charger		(63 Screws)	25.25
MO 1930 A	1966-67	Dodge Charger	Ext. Kit w/Wheel Well	(95 Screws)	38.05
MO 605	1968-70	Dodge Charger		(19 Screws)	8.05
MO 605 A	1968-70	Dodge Charger	Ext. Kit w/Wheel Well	(51 Screws)	20.85
MO 1351	1971	Dodge Charger R/T		(32 Screws)	18.50
MO 1351 A	1971	Dodge Charger R/T	Ext. Kit w/Wheel Well	(62 Screws)	30.50
MO 1350	1973	Dodge Charger SE		(48 Screws)	24.20
MO 1350 A	1973	Dodge Charger SE	Ext. Kit w/Wheel Well	(78 Screws)	36.20
MO 1730	1977	Dodge Cordova		(29 Screws)	12.70
MO 1730 A	1977	Dodge Cordova	Ext. Kit w/Wheel Well	(61 Screws)	25.50
MO 507	1953	Dodge Coronet		(16 screws)	6.30
MO 1865	1959	Dodge Coronet		(32 Screws)	13.00
MO 502	1965	Dodge Coronet		(26 Screws)	13.00
MO 502 A	1965	Dodge Coronet	Ext. Kit w/Wheel Well	(60 Screws)	26.60
MO 508	1966-67	Dodge Coronet		(39 Screws)	22.90
MO 508 A	1966-67	Dodge Coronet	Ext. Kit w/Wheel Well	(71 Screws)	35.70
MO 606	1969	Dodge Coronet		(37 Screws)	13.35
MO 606 A	1969	Dodge Coronet	Ext. Kit w/Wheel Well	(69 Screws)	26.15
MO 1775	1963	Dodge Polara		(43 Screws)	16.95
MO 1960	1967	Dodge Polara		(23 Screws)	10.75
MO 1960 A	1967	Dodge Polara	Ext. Kit w/Wheel Well	(55 Screws)	23.55
MO 1968	1973	Dodge Polara		(52 Screws)	25.60

Mr. G's Enterprises

5613 Elliott Reeder Road • Fort Worth, Texas 76117-6013

(817) 831-3501 • Fax # (817) 831-0638 • email : mrgs@mrgusa.com Webiste: www.mrgusa.com

Mopar Exterior Screw Kits

<u>Kit #</u>	<u>Year</u>	<u>Make/Model</u>	<u>Description</u>	<u>Screw Quantity</u>	<u>Price</u>
MO 1968 A	1973	Dodge Polara	Ext. Kit w/Wheel Well	(80 Screws)	36.80
MO 1845	1964-67	Dodge D-100 P/U		(34 Screws)	15.95
MO 603	1973	Dodge Pickup		(34 Screws)	14.60
MO 1840	1976-80	Dodge Pickup Little Red Express		(55 Screws)	25.30
MO 820	1984-88	Dodge Ram Charger Prospector		(18 Screws)	8.00
MO 607	1963	Ply. Valiant GT		(26 Screws)	12.00
MO 1885	1964	Ply.Val.Signet 200		(16 Screws)	6.20
MO 1885 A	1964	Ply. Valiant	Ext. Kit w/Wheel Well	(48 Screws)	19.00
MO 1887	1966	Ply. Valiant		(16 Screws)	7.50
MO 1887 A	1966	Ply. Valiant	Ext. Kit w/Wheel Well	(48 Screws)	20.30
MO 801	1968	Ply. Valiant		(30 Screws)	13.60
MO 801 A	1968	Ply. Valiant	Ext. Kit w/Wheel Well	(60 Screws)	25.60
MO 1990	1970-71	Plymouth Duster		(41 Screws)	18.30
MO 1991	1972-73	Plymouth Duster		(41 Screws)	20.10
MO 1886	1964-65	Plym. Barracuda		(12 Screws)	4.80
MO 1886 A	1964-65	Plym. Barracuda	Ext. Kit w/Wheel Well	(44 Screws)	17.60
MO 1940	1966	Plym. Barracuda		(14 Screws)	5.40
MO 1940 A	1966	Plym. Barracuda	Ext. Kit w/Wheel Well	(46 Screws)	18.30
MO 1941	1967	Plym. Barracuda		(12 Screws)	5.30
MO 1941 A	1967	Plym. Barracuda	Ext. Kit w/Wheel Well	(44 Screws)	18.00
MO 802	1968-69	Plym. Barracuda		(24 Screws)	10.80
MO 802 A	1968-69	Plym. Barracuda	Ext. Kit w/Wheel Well	(54 Screws)	22.80
MO 1950	1970-74	Plymouth Cuda		(32 Screws)	19.35
MO 1950 A	1970-74	Plymouth Cuda	Ext. Kit w/Wheel Well	(63 Screws)	31.55
MO 518	1948	Plymouth		(11 Screws)	4.80
MO 1995	1953	Plymouth		(16 Screws)	7.65
MO 806	1956	Plym.Savoy 4-Dr.		(28 Screws)	10.20
MO 1605	1954	Plym. Belvedere		(20 Screws)	8.60
MO 514	1957	Plym. Belvedere		(35 Screws)	15.75
MO 2000	1964	Plym.Belvedere		(18 Screws)	7.50
MO 501	1965	Plym. Belvedere		(48 Screws)	18.70
MO 501 A	1965	Plym. Belvedere	Ext. Kit w/Wheel Well	(78 Screws)	30.70
MO 1925	1966	Plym. Belv.-Satl.		(33 Screws)	17.25
MO 1925 A	1966	Plym. Belv.-Satl.	Ext. Kit w/Wheel Well	(63 Screws)	29.25
MO 604	1967	Plym. Belv.-Satl.		(21 Screws)	9.00
MO 604 A	1967	Plym. Belv.-Satl.	Ext. Kit w/Wheel Well	(53 Screws)	21.80
MO 511	1968	Plym. Belv.-Satl.		(32 Screws)	16.40

Mr. G's Enterprises

5613 Elliott Reeder Road • Fort Worth, Texas 76117-6013

(817) 831-3501 • Fax # (817) 831-0638 • email : mrgs@mrgusa.com Webiste: www.mrgusa.com

Mopar Exterior Screw Kits

<u>Kit #</u>	<u>Year</u>	<u>Make/Model</u>	<u>Description</u>	<u>Screw Quantity</u>	<u>Price</u>
MO 511 A	1968	Plym. Belv.-Satl.	Ext. Kit w/Wheel Well	(64 Screws)	29.20
MO 1780	1969	Ply. Roadrunner		(21 Screws)	9.70
MO 1780 A	1969	Ply. Roadrunner	Ext. Kit w/Wheel Well	(53 Screws)	22.50
MO 1781	1970	Ply. Roadrunner		(17 Screws)	9.30
MO 1781 A	1970	Ply. Roadrunner	Ext. Kit w/Wheel Well	(49 Screws)	22.10
MO 1795	1963	Ply.Sport Fury		(35 Screws)	16.50
MO 1420	1964	Ply.Sport Fury		(37 Screws)	17.10
MO 1741	1970	Ply. Fury		(24 Screws)	12.90
MO 2002	1987	Ply. Gran Fury		(16 Screws)	5.80
MO 2001	1986	Chrysler LeBaron		(14 Screws)	11.50
MO 1955	1964	Chrysler Newport		(18 Screws)	9.00
MO 1915	1965-66	Chrysler Newport		(26 Screws)	11.30
MO 1740	1969	Chrysler Newport		(26 Screws)	10.05
MO 800	1962	Chrys. New Yorker	(4-Dr. H/T)	(22 Screws)	10.40
MO 1880	1957	Chrysler Windsor		(10 Screws)	4.70

AMC Exterior Screw Kits

AM 825	1965	Rambler Classic		(27 Screws)	10.80
AM 826	1965	Ambassador		(21 Screws)	8.10