

# Mr. G's Enterprises

5613 Elliott Reeder Road • Fort Worth, Texas 76117-2013

(817) 831-3501 • (817) 838-3131 • Fax # (817) 831-0638 • email : mrgs@earthlink.net

## Mopar Interior Screw Kits

<u>Kit #</u>	<u>Year</u>	<u>Make/Model</u>	<u>Description</u>	<u>Screw Quantity</u>	<u>Price</u>
MO 1300	1963	Dodge Dart 170	(4-Dr.)	(65 Screws)	23.40
MO 1301	1963	Dodge Dart 170	(Conv.)	(89 Screws)	32.10
MO 1580	1964	Dodge Dart	(4-Dr.)	(83 Screws)	30.70
MO 1710	1964	Dodge Dart 270	(Conv.)	(83 Screws)	29.95
MO 515	1964	Dodge Dart 270	(2-Dr. H/T)	(145 Screws)	57.70
MO 1890	1964	Dodge Dart GT	(2-Dr. H/T)	(150 Screws)	57.80
MO 1260	1965	Dodge Dart	(2-Dr.)	(107 Screws)	46.00
MO 1261	1965	Dodge Dart 270	(conv.)	(105 Screws)	44.60
MO 1270	1965	Dodge Dart GT	(2-Dr.)	(141 Screws)	56.70
MO 1280	1966	Dodge Dart	(4-Dr.)	(106 Screws)	48.05
MO 1290	1967-69	Dodge Dart	(2-Dr.)	(107 Screws)	40.55
MO 1450	1967-69	Dodge Dart	(Conv.)	(93 Screws)	31.85
MO 1675	1970-72	Dodge Dart	(2-Dr. H/T)	(106 Screws)	37.25
MO 1670	1970-74	Dodge Dart	(4-Dr.)	(65 Screws)	23.85
MO 1665	1974-75	Dodge Dart	(2-Dr. H/T)	(96 Screws)	36.30
MO 1465	1970-74	Cuda-Challenger	(Conv.)	(129 Screws)	47.80
MO 1470	1970-74	Cuda-Challenger	(2-Dr. H/T)	(148 Screws)	53.90
MO 1825	1950	Dodge	(2-Dr.Sedan)	(88 Screws)	34.05
MO 1565	1966-67	Dodge Charger	(2-Dr.)	(173 Screws)	61.30
MO 1905	1966-67	Dodge Charger	(Console Kit)	(47 Screws)	17.70
MO 1505	1968	Dodge Charger	(2-Dr.)	(97 Screws)	33.15
MO 1750	1969-70	Dodge Charger	(2-Dr.)	(114 Screws)	37.45
MO 1340	1971-74	Dodge Charger S.E.	(2-Dr.)	(84 Screws)	29.35
MO 1341	1971-74	Dodge Charger R/T	(2-Dr.)	(106 Screws)	37.80
MO 1725	1977	Dodge Cordova	(2-Dr.)	(89 Screws)	29.95
MO 1945	1953	Dodge Coronet	(4-Dr.)	(100 Screws)	35.05
MO 1860	1959	Dodge Coronet	(4-Dr.Sedan)	(123 Screws)	47.65
MO 1550	1963	Dodge 330	(4-Dr.)	(101 Screws)	37.00
MO 1250	1964	Dodge Coronet 440 & 500	(2-Dr.H/T)	(153 Screws)	61.75
MO 1425	1965	Dodge Coronet 440	(4-Dr.)	(102 Screws)	38.75
MO 1430	1965	Dodge Coronet 440	(2-Dr.H/T)	(116 Screws)	43.20
MO 1554	1965	Dodge Coronet 500	(2-Dr.H/T)	(138 Screws)	51.20
MO 1555	1965	Dodge Coronet 500	(Conv.)	(138 Screws)	63.90
MO 1620	1966	Dodge Coronet 440	(4-Dr.)	(101 Screws)	38.10
MO 1720	1966	Dodge Coronet 500	(2-Dr.)	(113 Screws)	41.90
MO 1625	1966	Dodge Coronet 440 & 500	(Conv.)	(87 Screws)	31.25

# Mr. G's Enterprises

5613 Elliott Reeder Road • Fort Worth, Texas 76117-2013

(817) 831-3501 • (817) 838-3131 • Fax # (817) 831-0638 • email : mrgs@earthlink.net

## Mopar Interior Screw Kits

<u>Kit #</u>	<u>Year</u>	<u>Make/Model</u>	<u>Description</u>	<u>Screw Quantity</u>	<u>Price</u>
MO 1435	1967	Dodge Coronet 440 & 500	(Conv.)	(103 Screws)	36.35
MO 1330	1967	Dodge Coronet 440	(4-Dr.)	(85 Screws)	31.70
MO 1320	1967	Dodge Coronet 440	(2-Dr.)	(98 Screws)	34.75
MO 1640	1968	Dodge Coronet	(4-Dr.)	(102 Screws)	37.95
MO 1641	1968	Dodge Coronet	(Conv.)	(84 Screws)	29.40
MO 1642	1968	Dodge Coronet	(2-Dr. H/T)	(106 Screws)	37.85
MO 1630	1969-70	Dodge Coronet 440 & 500	(Conv.)	(110 Screws)	38.90
MO 1635	1969-70	Dodge Coronet 440 & 500	(2-Dr. H/T)	(110 Screws)	39.25
MO 1160	1969-70	Dodge Coronet	(4-Dr.)	(114 Screws)	42.75
MO 1540	1964	Dodge Custom 880	(4-Dr.)	(151 Screws)	55.45
MO 1765	1963	Dodge Polara	(2-Dr.H/T)	(123 Screws)	46.90
MO 1766	1963	Dodge Polara	(Conv.)	(113 Screws)	43.10
MO 1250	1964	Dodge Polara 500	(2 Dr. H/T)	(147 Screws)	61.75
MO 1575	1964	Dodge Polara	(Conv.)	(98 Screws)	35.50
MO 1200	1967	Dodge Polara	(4-Dr.)	(112 Screws)	49.05
MO 1745	1967	Dodge Polara	(2-Dr. H/T)	(136 Screws)	45.75
MO 1746	1967	Dodge Polara	(Conv.)	(116 Screws)	39.35
MO 1966	1973	Dodge Polara	(4-Dr. H.T.)	(111 Screws)	37.70
MO 1850	1964-67	Dodge D-100 Pickup		(45 Screws)	16.20
MO 600	1973	Dodge Pickup		(63 Screws)	22.60
MO 1835	1976-80	Dodge Pickup	Little Red Express	(52 Screws)	19.55
MO 1842	1984-88	Dodge Ram Charger	Prospector	(137 Screws)	56.65
MO 1210	1962	Plymouth Valiant	(4-Dr.Sedan)	(77 Screws)	37.20
MO 609	1963	Plymouth Valiant GT	(Conv.)	(98 Screws)	38.35
MO 608	1963	Plymouth Valiant GT	(2-Dr.H/T)	(95 Screws)	35.60
MO 1870	1964	Plymouth Valiant Signet 200	(2-Dr.H/T)	(112 Screws)	39.65
MO 1711	1964	Plymouth Valiant	(Conv.)	(83 Screws)	29.95
MO 1585	1964-66	Plymouth Valiant	(2-Dr.Sedan)	(71 Screws)	26.00
MO 1685	1967	Plymouth Valiant	(2-Dr.Sedan)	(55 Screws)	20.80
MO 1690	1967	Plymouth Valiant	(4-Dr.Sedan)	(57 Screws)	21.50
MO 517	1968	Plymouth Valiant Signet	(4-Dr.Sedan)	(66 Screws)	24.95
MO 1700	1970-72	Plymouth Valiant	(2-Dr. H/T)	(82 Screws)	27.00
MO 1660	1972	Plymouth Valiant Duster	(2-Dr.Sedan)	(63 Screws)	23.90
MO 509	1974	Plymouth Valiant Duster		(98 Screws)	33.95
MO 1405	1964-65	Plymouth Barracuda	(2-Dr.)	(135 Screws)	45.30
MO 1815	1966	Plymouth Barracuda	(F/B)	(165 Screws)	53.85

# Mr. G's Enterprises

5613 Elliott Reeder Road • Fort Worth, Texas 76117-2013

(817) 831-3501 • (817) 838-3131 • Fax # (817) 831-0638 • email : mrgs@earthlink.net

## Mopar Interior Screw Kits

<u>Kit #</u>	<u>Year</u>	<u>Make/Model</u>	<u>Description</u>	<u>Screw Quantity</u>	<u>Price</u>
MO 1120	1967	Plymouth Barracuda	(Reg. Kit)	(90 Screws)	29.05
MO 1130	1967	Plym. Barracuda (Deluxe Kit)	(F/B)	(131 Screws)	39.30
MO 1121	1967	Plym. Barracuda	(Conv.)	(83 Screws)	28.00
MO 1122	1967	Plym. Barracuda	(Coupe w/F/D)	(87 Screws)	29.40
MO 1140	1968-69	Plym. Barracuda (Reg. Kit)	(Coupe-F/B)	(83 Screws)	28.95
MO 1150	1968-69	Plym. Barracuda (Deluxe Kit)	(F/B)	(117 Screws)	36.60
MO 1445	1968-69	Plym. Barracuda	(Conv.)	(83 Screws)	29.95
MO 500	1948-49	Plymouth	(4-Dr. Sedan)	(172 Screws)	82.40
MO 503	1953	Plymouth	(4-Dr. Sedan)	(74 Screws)	27.75
MO 519	1956	Plymouth	(4-Dr. Sedan)	(127 Screws)	51.60
MO 1900	1957	Plymouth Plaza	(2-Dr.Sedan)	(78 Screws)	29.20
MO 1600	1954	Plymouth Belvedere	(4-Dr.)	(99 Screws)	37.40
MO 513	1957	Plymouth Belvedere	(2-Dr. Sedan)	(83 Screws)	33.70
MO 1755	1964	Plymouth Belvedere	(2-Dr.H/T)	(116 Screws)	42.05
MO 1830	1965	Plymouth Belvedere II	(4-Dr.)	(107 Screws)	39.15
MO 1495	1965	Ply. Belvedere-Satellite	(2-Dr.)	(147 Screws)	52.25
MO 1475	1965	Ply. Belvedere-Satellite	(Conv.)	(111 Screws)	40.40
MO 1820	1966	Ply. Belvedere-Satellite	(2-Dr. H/T)	(116 Screws)	42.00
MO 1805	1966	Ply. Belvedere-Satellite	(Conv.)	(97 Screws)	35.35
MO 1610	1967	Ply. Belvedere-Satellite	(4-Dr.)	(84 Screws)	28.35
MO 601	1967	Plymouth Satl.-GTX	(2-Dr. H/T)	(113 Screws)	38.90
MO 1695	1967	Ply. GTX-Satellite	(Conv.)	(112 Screws)	38.20
MO 512	1968	Plymouth Satellite	(2-Dr. H/T)	(104 Screws)	36.45
MO 1440	1968	Ply. GTX-Satellite	(Conv.)	(101 Screws)	34.55
MO 1705	1968	Ply. GTX	(2-Dr.)	(118 Screws)	40.05
MO 1570	1968	Ply. Roadrunner	(2-Dr.)	(95 Screws)	32.00
MO 1455	1969-70	GTX-Roadrunner-Super Bee	(Conv.)	(106 Screws)	36.40
MO 1460	1969-70	GTX-Roadrunner-Super Bee	(2-Dr.)	(105 Screws)	36.50
MO 1490	1971-74	Plymouth Roadrunner	(2-Dr.)	(94 Screws)	33.85
MO 1760	1963	Plymouth Fury	(Conv.)	(102 Screws)	36.95
MO 1761	1963	Plymouth Fury	(2-Dr.H/T)	(109 Screws)	41.25
MO 1410	1964	Plymouth Fury	(2-Dr.)	(119 Screws)	42.25
MO 1415	1964	Plymouth Fury	(Conv.)	(100 Screws)	35.20
MO 1560	1965-66	Plymouth Fury	(Conv.)	(88 Screws)	34.05
MO 1230	1965-66	Plymouth Fury	(2-Dr.)	(112 Screws)	49.35
MO 1240	1965-66	Plymouth Fury	(4-Dr.)	(130 Screws)	61.75

# Mr. G's Enterprises

5613 Elliott Reeder Road • Fort Worth, Texas 76117-2013

(817) 831-3501 • (817) 838-3131 • Fax # (817) 831-0638 • email : mrgs@earthlink.net

## Mopar Interior Screw Kits

<u>Kit #</u>	<u>Year</u>	<u>Make/Model</u>	<u>Description</u>	<u>Screw Quantity</u>	<u>Price</u>
MO 1645	1967	Plymouth Fury	(2-Dr. H/T)	(111 Screws)	39.60
MO 1310	1967	Plymouth Fury	(4-Dr.)	(89 Screws)	31.30
MO 1646	1967	Plymouth Fury	(Conv.)	(91 Screws)	32.80
MO 1650	1968	Plymouth Fury	(2-Dr. H/T)	(119 Screws)	41.40
MO 1315	1968	Plymouth Fury	(4-Dr.)	(91 Screws)	34.00
MO 1655	1969	Plymouth Fury	(4-Dr.Sedan)	(73 Screws)	25.15
MO 1656	1969	Plymouth Fury	(2-Dr.H/T)	(94 Screws)	30.45
MO 1657	1969	Plymouth Fury	(Conv.)	(101 Screws)	33.40
MO 1658	1970	Plymouth Fury	(Conv.)	(75 Screws)	24.85
MO 1997	1987	Plymouth Gran Fury	(4-Dr. Sedan)	(72 Screws)	27.65
MO 1996	1986	Chrysler LeBaron	(Conv.)	(97 Screws)	42.45
MO 1510	1957	Chrysler 300	(2-Dr. H/T)	(87 Screws)	31.90
MO 1515	1963	Chrysler 300	(2-Dr. H/T)	(109 Screws)	40.00
MO 1525	1966	Chrysler 300	(2-Dr.)	(146 Screws)	50.45
MO 1810	1962	Chrysler Newport	(4-Dr.Sedan)	(148 Screws)	50.40
MO 1855	1964	Chrysler Newport	(4-Dr.Sedan)	(158 Screws)	57.15
MO 1910	1965	Chrysler Newport	(2-Dr. H/T)	(112 Screws)	39.35
MO 1615	1965-66	Chrysler Newport	(4-Dr.Sedan)	(90 Screws)	32.75
MO 1528	1967	Chrysler Newport	(4-Dr. Sedan)	(108 Screws)	47.70
MO 1180	1968	Chrysler Newport	(2-Dr.H/T)	(129 Screws)	44.30
MO 1530	1968	Chrysler Newport	(4-Dr.)	(108 Screws)	38.55
MO 1735	1969	Chrysler Newport	(2-Dr.H/T)	(100 Screws)	34.10
MO 1360	1954	Chrysler New Yorker	(4-Dr.)	(126 Screws)	44.50
MO 1370	1956	Chrysler New Yorker	(4-Dr.)	(122 Screws)	44.40
MO 516	1962	Chrysler New Yorker	(4-Dr.H/T)	(156 Screws)	58.20
MO 1520	1963	Chrysler New Yorker	(4-Dr.)	(131 Screws)	45.65
MO 1535	1968	Chrysler New Yorker	(4-Dr.)	(108 Screws)	39.05
MO 1875	1957	Chrysler Windsor	(2-Dr. H/T)	(126 Screws)	49.15

## AMC Interior Screw Kits

AM 550	1965	Rambler Classic 660	(4-Dr.Sedan)	(114 Screws)	44.60
AM 555	1965	Ambassador 880	(4-Dr.Sedan)	(98 Screws)	39.35